

# Gebote Boot


 <p>Keep clear. Exit for emergency escape route</p> <p><b>SIG-0376</b></p>	 <p>This door must be kept closed</p> <p><b>SIG-0377</b></p>	 <p><b>Keep clear</b></p> <p><b>SIG-0378</b></p>	 <p>Close this door at night</p> <p><b>SIG-0379</b></p>	 <p>Close these doors at night</p> <p><b>SIG-0380</b></p>
 <p>This door to be kept locked when not in use</p> <p><b>SIG-0381</b></p>	 <p>To be kept unlocked during working hours</p> <p><b>SIG-0382</b></p>	 <p>Fire door keep locked shut</p> <p><b>SIG-0383</b></p>	 <p>Automatic fire door keep clear</p> <p><b>SIG-0384</b></p>	 <p>Staircase must be kept clear at all times</p> <p><b>SIG-0385</b></p>
 <p>Fire escape keep clear</p> <p><b>SIG-0386</b></p>	 <p>Gangway keep clear</p> <p><b>SIG-0387</b></p>	 <p>Fire door keep shut</p> <p><b>SIG-0388</b></p>	 <p>Keep locked shut when not in use</p> <p><b>SIG-0389</b></p>	 <p>Keep clear when door is closing</p> <p><b>SIG-0390</b></p>
 <p>This hatch must be kept closed at sea</p> <p><b>SIG-0391</b></p>	 <p>This door must be kept closed at sea</p> <p><b>SIG-0392</b></p>	 <p>Watertight door keep shut</p> <p><b>SIG-0393</b></p>	 <p>Automatic watertight door keep clear</p> <p><b>SIG-0394</b></p>	 <p>Ensure this door is fully closed</p> <p><b>SIG-0395</b></p>
 <p><b>Exit keep clear</b></p> <p><b>SIG-0396</b></p>	 <p><b>!</b> Persons entering this area must comply with safety regulations</p> <p><b>SIG-0397</b></p>	 <p><b>!</b> Ventilation to be used prior to entry</p> <p><b>SIG-0398</b></p>	 <p><b>!</b> No fire traps to be installed without the knowledge of the watch officer. No fire traps to be kept installed for longer than the period required. Signed: _____ Master</p> <p><b>SIG-0399</b></p>	 <p><b>!</b> All visitors to report to the duty officer on the bridge</p> <p><b>SIG-0400</b></p>
 <p><b>!</b> <b>Keep clear</b></p> <p><b>SIG-0401</b></p>	 <p><b>!</b> <b>Keep shut</b></p> <p><b>SIG-0402</b></p>	 <p><b>!</b> This door must be kept closed during loading, discharging, ballasting, tank cleaning and gas freeing operations</p> <p><b>SIG-0403</b></p>	 <p><b>!</b> When the plant is not in use gas cylinder valves and other valves shall be shut</p> <p><b>SIG-0404</b></p>	 <p><b>!</b> Adjust pressure according to the torch in use</p> <p><b>SIG-0405</b></p>
 <p><b>!</b> Secure painter to strong point before launching</p> <p><b>SIG-0406</b></p>	 <p><b>!</b> <b>CO<sub>2</sub> Protected area</b> On hearing alarm vacate space immediately. Close all exits behind you.</p> <p><b>SIG-0407</b></p>	 <p><b>!</b> <b>Man overboard</b> 1. Throw lifebuoy. 2. Keep man in sight. 3. Inform the bridge or the officer of the watch. 4. State man overboard and give location.</p> <p><b>SIG-0408</b></p>	 <p><b>!</b> <b>EMERGENCY EVACUATION INSTRUCTIONS</b> Know the NUMBER and LOCATION of your personal assembly station. When you hear alarm check and see how long to the clear alarm sound and then: 1. Collect your equipment and wear it. 2. Be immediately to your station. 3. Remain orderly and quiet. 4. Stay calm. 5. Stay with your group. 6. Stay until you are told to leave. 7. Report any problems. DO NOT use elevators. DO NOT use any lifts.</p> <p><b>SIG-0409</b></p>	 <p><b>!</b> <b>EMERGENCY EXIT KEEP CLEAR</b></p> <p><b>SIG-0410</b></p>



**SIG-0411**



**SIG-0412**



**SIG-0413**

